

Follow installation procedure in instructions supplied with unit with the following exceptions:

1. Remove center knockout in backbox (H).
2. Assemble one end of pendant stem (F) to backplate using locknuts (G) and washers (I) and (J) as shown.
3. Assemble canopy (D), pivot ball (E) and remaining end of pendant stem together as shown.
4. Assemble cross bar (B) to outlet box.
5. Feed an appropriate length of AC service wire through pendant stem assembly and cross bar.
6. Make AC connections at outlet box and snap canopy over cross bar.
7. Complete assembly per unit instructions.

PART CODE	DESCRIPTION	QTY.
A	OUTLET BOX - BY OTHERS	1
B	CROSSBAR	1
C	SCREW - BY OTHERS	2
D	CANOPY	1
E	BALL PIVOT	1
F	PENDANT STEM	1
G	LOCKNUT 1/4 I.P.	2
H	UNIT BACKBOX	1
I	FLAT WASHER 1/2" x 7/8"	2
J	LOCK WASHER 1/4 I.P.	1

